
PowerINSPECT 2016

Installation Guide



PowerINSPECT

Copyright © 1993-2015 Delcam Ltd. All rights reserved.

Delcam Ltd has no control over the use made of the software described in this manual and cannot accept responsibility for any loss or damage howsoever caused as a result of using the software. Users are advised that all the results from the software should be checked by a competent person, in accordance with good quality control procedures.

The functionality and user interface in this manual is subject to change without notice in future revisions of software.

The software described in this manual is furnished under licence agreement and may be used or copied solely in accordance with the terms of such licence.

Delcam Ltd grants permission for licensed users to print copies of this manual or portions of this manual for personal use only. Schools, colleges and universities that are licensed to use the software may make copies of this manual or portions of this manual for students currently registered for classes where the software is used.

Acknowledgements

This documentation references a number of registered trademarks and these are the property of their respective owners. For example, Microsoft and Windows are either registered trademarks or trademarks of Microsoft Corporation in the United States.

Contents

Introduction	1
Before Installing	2
Requirements	3
Hardware	3
Software	4
Dongle and protection file	4
Installing PowerINSPECT	6
Installing the licence file	7
Setting the language	8
Connecting to measuring devices	9
Configuring the connection	10
Selecting the connection protocol	10
Setting the connection protocol parameters	11
Setting error mapping	11
Checking the connection	12
Configuring sounds	13
Troubleshooting	14
Dongle error messages	14
Problems using Microsoft Excel	15

Introduction

Read this document before installing PowerINSPECT 2016. It describes how to install PowerINSPECT, and also includes information on how to upgrade from previous versions, how to configure PowerINSPECT, and how to handle some of the common problems that may be encountered.

Before Installing

If you already have an installation of PowerINSPECT, back up all custom information associated with the installation, including custom report templates.

Uninstall any beta or prerelease versions of PowerINSPECT because these can interfere with its installation and use. You do not need to uninstall previous release versions of PowerINSPECT.


Remove all USB dongles, including those required by other products, before starting the installation. Do not re-insert the dongles until the installation is complete and the computer has restarted. This is necessary because the software which PowerINSPECT uses to communicate with dongles may not install correctly if a dongle is inserted during the driver installation.

Requirements

Before starting the installation, make sure your computer meets the minimum hardware requirements for PowerINSPECT 2016 and that all necessary software is installed.

Hardware

The following specification is recommended for a new installation of PowerINSPECT:

Hardware	Workstation PC designed to run engineering and 3D applications
Processor	Multiple core 64-bit processor, such as AMD Phenom II or Intel Core i7
RAM	4GB minimum 16GB or more recommended for demanding parts
Graphics card	NVIDIA Quadro  <i>AMD and ATI graphics cards, such as Radeon and FireGL, are not supported.</i>

For larger CAD files, a faster processor, more RAM, and a more powerful graphics card will give better performance.

Software

PowerINSPECT 2016 can be used with the following operating systems:

- 64-bit Windows 7 Professional with Service Pack 1, 64-bit Windows 7 Enterprise with Service Pack 1 and 64-bit Windows 7 Ultimate with Service Pack 1.
- 64-bit Windows 8 Pro and 64-bit Windows 8 Enterprise.
- 64-bit Windows 8.1 Pro and 64-bit Windows 8.1 Enterprise.
- 64-bit Windows 10 Pro, 64-bit Windows 10 Enterprise and 64-bit Windows 10 Education.



PowerINSPECT is only available as a 64-bit application. 32-bit versions of Windows are not supported.



PowerINSPECT is not available for Windows RT or Windows 10 Mobile. Windows RT and Windows 10 Mobile are variations of Windows for devices like tablets. Windows RT and Windows 10 Mobile only supports third-party applications purchased through the Windows Store.

Microsoft Internet Explorer

PowerINSPECT 2016 requires Microsoft Internet Explorer versions 9, 10 or 11. You can install the latest version of Internet Explorer using Windows Updates, or download it from the Microsoft website at:

<http://www.microsoft.com/windows/internet-explorer/default.aspx>

Microsoft Excel

PowerINSPECT 2016 can generate printed reports using its own internal HTML format and Microsoft Excel. If you want to use Excel to generate reports then Excel 2010 or Excel 2013 are required. PowerINSPECT works with both the 32-bit and 64-bit versions of Excel but the 32-bit version of Excel is recommended.

Adobe Acrobat

If you want to export reports to Portable Document Format (PDF), you must install Adobe Acrobat or another application that converts print output to PDF files.

Dongle and protection file

PowerINSPECT requires a valid dongle and licence file. These are provided by your sales representative.

For more information, see Installing the licence file (see page 7).

Installing PowerINSPECT

To install PowerINSPECT:

- 1 Log on to the computer as a user with administrative privileges.
- 2 Insert the PowerINSPECT disc into your computer's disc drive. If the installation does not start automatically, open the disc drive folder in Windows Explorer, and double-click **Setup.exe**.
- 3 Follow the on-screen installation instructions. The installer checks your computer meets the minimum system requirements (see page 3).

If your operating system is not supported, or a service pack or Internet Explorer is required, the installer informs you which components are needed and stops. If this happens, install the specified components, then restart the installation.

- 4 When the installation is complete, install your license file (see page 7).
- 5 Ensure the date and time on your computer are correct.



Changing the time and date after using PowerINSPECT can cause the dongle to lock. If this happens, contact your sales representative for assistance.

- 6 Insert your dongle and run PowerINSPECT.

Installing the licence file

In the PAF licensing system, you must install a Product Authorisation File (PAF), which contains your personal authorisation codes, on the computer where PowerINSPECT is to be used. You must also insert a dongle in one of the computer's ports.

The licence file is normally sent to you by your sales representative as an email attachment. After you have installed PowerINSPECT and restarted your computer, follow the email instructions to install the PAF. Do not move the PAF from the installation folder; an error message is displayed if PowerINSPECT cannot find the file when it is started. There must be only one PAF in this folder. You must delete or rename any previous versions of the PAF; otherwise, PowerINSPECT may not work correctly. For more information, contact your sales representative.



PowerINSPECT can also be licensed under the network licensing system. This is a cost option, which restricts the number of simultaneous users, but not which computer the software is running on. The network licensing system is not described in this document.


Setting the language

When you start PowerINSPECT, you can configure the language used in the PowerINSPECT information window. This must be done *before* opening a file – you cannot set the language while an inspection session is open.

To set the language:

- 1 Select the **Edit > Language** menu option.
- 2 In the **List of all available languages** dialog, select the language you want to use, then click **OK**.

Connecting to measuring devices

When PowerINSPECT is running, the connection  icon is displayed in the Windows taskbar.

The colour of the icon indicates the state of the connection between PowerINSPECT and the measuring device:

RED	PowerINSPECT is not connected to the measuring device.
GREEN	PowerINSPECT is connected to the measuring device, but not collecting contact points.
BLUE	PowerINSPECT is connected to the measuring device and collecting contact points for inspection.
YELLOW	PowerINSPECT is connected to the measuring device and collecting contact points for calibration.

Configuring the connection

The connection to your measuring device is made using the **CMMDriver Configuration** dialog. It enables you to select the connection protocol, the protocol parameters, and to configure error mapping for the connection.

To open the configuration dialog, select the **Tools > Machine Connection > Configuration** menu option.



Normally, you do not need to configure the connection to your measuring device. If you are installing PowerINSPECT for the first time, this procedure should be carried out by your sales representative; if you are upgrading from a previous version of PowerINSPECT, your existing protocol configuration is automatically copied to the new version by the installation process.

Selecting the connection protocol

To set the connection protocol:

- 1 Click **Select** in the **Connection protocol** section of the **CMM Driver Configuration** dialog. The **Select Connection Protocol** dialog lists the available measuring devices.
- 2 Select the measuring device with which you want to use PowerINSPECT, then click **OK**.

If your measuring device is not listed, complete the PowerINSPECT CMM Questionnaire on the installation DVD and contact your sales representative. A Microsoft Word version of the questionnaire is available in \Documentation\PICMMQuestionnaire.doc; an Adobe Acrobat version is available in \Documentation\PICMMQuestionnaire.pdf.

Setting the connection protocol parameters

When you have selected the connection protocol for your measuring device, you must set the protocol parameters.

To set the connection protocol parameters:

- 1 Click **Parameters** in the **CMM Driver Configuration** dialog. A dialog displays the parameters required by the connection protocol. The name and contents of the parameters dialog depend on the protocol you select.
- 2 Enter the protocol parameters, and click **OK**.



For more information on the parameters, refer to your measuring device manual or contact your sales representative.

- 3 If your measuring device is not error mapped (see page 11), close the **CMM Driver Configuration** dialog.

Setting error mapping

If your measuring device is error mapped using a system that supports PowerINSPECT, you must configure error mapping for the connection.




Error mapping should only be carried out by an experienced CMM retrofitter. For more information on error mapping, contact your sales representative.

To set the error mapping:

- 1 Select the **Error mapping enabled** check box in the **CMMDriver Configuration** dialog.
- 2 Click **Select** in the **Error mapping** section. The **Select Error Map** dialog lists the error map types that are available.
- 3 Select the error map you want to use, then click **OK**.
- 4 In the **CMMDriver Configuration** dialog, click **Settings**. The **Error Map Settings** dialog is displayed.
- 5 Enter the error map values, and the location of the error map file. Click **OK** to close the dialog.
- 6 In the **CMM Driver Configuration** dialog, click **Close**.

Checking the connection

To test the connection to the measuring device, select the **Tools > Machine Connection > Connection** menu option to activate the connection, and check the connection  icon in the Windows task bar:

If the icon does not turn green, the connection has failed and an error message is displayed. If this happens, contact your sales representative for support.



The icon is only a guide to the state of your connection. To ensure the connection is established, take points with your measuring device and check that they are received by PowerINSPECT.

Configuring sounds

If a sound card is installed on your computer, PowerINSPECT can play a different sound for each inspection event. For example, it can play one sound when a measured point falls within tolerance, and another sound when a measured point is out of tolerance. This enables you to perform inspections without the need to check the screen for the result of each inspection event.

To customize the PowerINSPECT sound scheme:

- 1 Click the Windows **Start** button, and select **Control Panel > Sounds and Audio Devices**.
- 2 In the **Sound and Audio Device Properties** dialog, select the **Sounds** tab.
- 3 Scroll down the **Program events** list to the **PowerINSPECT** events.
- 4 Select the first PowerINSPECT event, and select a .wav file in the **Sounds** list.



Additional sound files are available in the \Redist\Sounds folder on the installation disc.

- 5 Repeat step 4 for each PowerINSPECT event.
- 6 Click **OK** to close the dialog.

Troubleshooting

This section describes how to deal with some of the most commonly encountered problems when using PowerINSPECT. Help is also available from the knowledge base articles included on the installation DVD. Consult the ReadMe file in the root of the DVD for more information.

Dongle error messages

PowerINSPECT will not start, and displays one of the following messages:

NO DONGLE FOUND ! Please plug-in the Dongle and press OK

Check the PowerINSPECT dongle is correctly connected to the computer.

If you have several parallel port dongles, try changing the order in which they are connected.

Make sure the latest version of the Sentinel driver is correctly installed. Reboot the computer after the installation. (To check the driver, click the Windows **Start** menu, select **All Programs > Control Panel > All Control Panel Items > Programs and Features**, and locate **Sentinel Protection Installer**.)

Ensure that only the current PAF file is in the licence file folder and that all old PAF files are removed. For more information, see Installing the licence file (see page 7).

Password Not Found in the protection file for this Software

Verify the contents of the dcam.paf file or contact your sales representative.

Your PowerINSPECT licence may have expired. Contact your sales representative for a code renewal.



Do not change the system date! This will not solve the problem and will cause another one.

Check that the dcam.paf file is really a full ASCII text file. Use the **PAF Wizard** to avoid these problems. (To open the wizard from the Windows **Start** menu, select **All Programs > Delcam > PAFWizard > PAF Wizard.**)

The Dongle is connected but PowerINSPECT refuses to start

Check the dongle is connected properly.

Use the **PAF Wizard** to check the state of the dongle. If it appears to be correct, the dongle may be faulty. (To open the wizard from the Windows **Start** menu, select **All Programs > Delcam > PAFWizard > PAF Wizard.**)

Problems using Microsoft Excel

The Excel MACRO has failed to create the REPORT because NO PRINTER HAS BEEN INSTALLED on your computer. Please Install a printer and start again.

Check that a printer driver is installed and configured for Windows even if you are using PowerINSPECT on a computer without a printer.

Update the page setup of each template file with a correct paper format, then try again.

Compiler Error

Check that the **MS GRAPH** option is installed. If it isn't, install the option and try again.

The Excel window is locked and cannot be used

Select the **File > Launch Excel** menu option in PowerINSPECT to unlock Excel.